



TSUNAMI T1 FRONT LIP FOR 94-97 INTEGRA INSTALLATION INSTRUCTIONS

IMPORTANT:

READ MOUNTING INSTRUCTIONS THOROUGHLY BEFORE STARTING! TSUNAMI PRODUCTS ACCEPT NO LIABILITY FOR DAMAGE INCURRED TO PARTS OR VEHICLES DUE TO IMPROPER PREPARATION AND/OR INSTALLATION PROCEDURES! DAMAGE CAUSED BY OR TO CARWASH FACILITIES IS THE RESPONSIBILITY OF THE VEHICLE OWNER! PARTS MODIFIED, PREPPED OR PAINTED CANNOT BE RETURNED!

TOOLS REQUIRED

- Power drill
- 3/8" Drill bit

- 1) Start by removing the front bumper off the car.
- 2) Then remove the stock lip from the front bumper and keep all the hardware.
- 3) Place the tsunami lip and the stock front bumper together and mark on the tsunami lip where the factory bolt holes are. (The holes were the bolts held went through to hold the stock lip on.)
- 4) Remove the tsunami lip and drill out the holes with the drill bit. Then place it back on the front bumper and use the factory hardware to secure the lip to the bumper.