



## TSUNAMI REAR BUMPER FOR 2002 – UP HONDA CIVIC SI

### IMPORTANT:

READ MOUNTING INSTRUCTIONS THOROUGHLY BEFORE STARTING! TSUNAMI PRODUCTS ACCEPT NO LIABILITY FOR DAMAGE INCURRED TO PARTS OR VEHICLES DUE TO IMPROPER PREPARATION AND/OR INSTALLATION PROCEDURES! DAMAGE CAUSED BY OR TO CARWASH FACILITIES IS THE RESPONSIBILITY OF THE VEHICLE OWNER! PARTS MODIFIED, PREPPED OR PAINTED CANNOT BE RETURNED!

PARTS LIST		TOOLS REQUIRED
Use factory hardware		<ul style="list-style-type: none"><li>• Phillips screw driver</li><li>• Power drill</li><li>• drill bit</li><li>• 10mm socket and wrench</li><li>• Pliers</li></ul>



1) Remove the factory rear bumper cover from the car and save your factory hardware. Place the Tsunami K2 front bumper onto the car and align it into the desired position mark all mounting holes.



2) Remove the tsunami bumpers and drill out each hole using a drill bit.



3) cut out the slots on the topside of the bumper and the trunk mounting holes



4) Place the tsunami rear bumper back onto the car and use the factory hardware to fasten down the bumper.