



## TSUNAMI T1 FRONT LIP SPOILER FOR ACRURA INSTALLATION INSTRUCTIONS

### IMPORTANT:

READ MOUNTING INSTRUCTIONS THOROUGHLY BEFORE STARTING! TSUNAMI PRODUCTS ACCEPT NO LIABILITY FOR DAMAGE INCURRED TO PARTS OR VEHICLES DUE TO IMPROPER PREPARATION AND/OR INSTALLATION PROCEDURES! DAMAGE CAUSED BY OR TO CARWASH FACILITIES IS THE RESPONSIBILITY OF THE VEHICLE OWNER! PARTS MODIFIED, PREPPED OR PAINTED CANNOT BE RETURNED! PLEASE REFER TO OUR PAINT INSTRUCTIONS FOR PAINTING.

### PARTS LIST

- Self-tapping screws – 4
- 3M double sided tape
- 3M adhesive promoter

### TOOLS REQUIRED

- Phillips screw driver
- Power drill
- Scotch bright pad

For installation of the RSX front lip spoiler, follow the instructions for the ford mustang lip spoiler or the general installation instructions for the front lip spoiler. Note that you will have to take off the factory lip located on the bottom of the factory bumper. Also, make sure you apply the 3M tape across the top of the spoiler were it meets the bumper opening for the fog lights.