



7) Press firmly everywhere on the rear valance where the bumper and it meet to make sure everything is snug and tight.



8) Use 2 self-tapping screws on both ends to secure the rear valance to the rear bumper and remove the clamps.



9) (Optional) - For added security, you can use the small screws to fasten the rear valance and the rear bumper by screwing the two together through the INSIDE of the bumper cover. Make sure you space each screw about 3" to 4" apart from each other and also make sure you measure the right distance from the top so that you do not screw through the rear bumper and miss the rear valance.



10) make sure you have about $\frac{3}{4}$ " clearance between the rear valance and the top of the exhaust pipe. If you don't, you run the risk of melting the rear valance.