



7) Use a 2 self tapping screws to fasten the side skirt from the front and back. (Note: make sure you remove the factory screws first and then screw a self tapping screw through to were the factory screw use to be.



8) there are two tabs on the bottom of the Tsunami side skirt. Use a 1/8" drill bit and drill a hole in the center of each of the tabs.



9) then use the spacers provided and place them in between the factory side skirt and the Tsunami side skirt. Then use the longer screws to fasten the two together. The longer ones are for the rear and the shorter ones are for the front.



10) do the same for both sides.