



## TSUNAMI ROOF WING INSTALLATION INSTRUCTIONS

### IMPORTANT:

READ MOUNTING INSTRUCTIONS THOROUGHLY BEFORE STARTING! TSUNAMI PRODUCTS ACCEPT NO LIABILITY FOR DAMAGE INCURRED TO PARTS OR VEHICLES DUE TO IMPROPER PREPARATION AND/OR INSTALLATION PROCEDURES! DAMAGE CAUSED BY OR TO CARWASH FACILITIES IS THE RESPONSIBILITY OF THE VEHICLE OWNER! PARTS MODIFIED, PREPPED OR PAINTED CANNOT BE RETURNED! PLEASE REFER TO OUR PAINT INSTRUCTIONS FOR PAINTING.

### PARTS LIST

- 3M double sided tape
- 3M adhesive promoter

### TOOLS REQUIRED

- Scotch bright pad



1) Clean and wash your rear window before installing. Clean the roof wing and rub with a scotch bright pad. Apply the 3M adhesive promoter to the cleaned area on the wing.



2) Apply the 3M double-sided tape to the wing and make sure the tape is firmly applied to the wing.



3) Then start to peel the red backing off the tape. Only peel 2" to 3" of the backing and fold it over the top of the tsunami wing.



4) Place the wing onto the rear window of your car and make sure it is centered and straight. Then hold down firmly on the wing and begin pulling the red backing off the double-sided tape.



5) Pull off all the red backing from the tape and press firmly down on the wing to make sure it is set in place.