



## **VW BEETLE 1998 – UP– INSTALLATION INSTRUCTIONS**

To secure the Front Spoiler it will be necessary to mark and drill four 1/8" mounting holes through the bottom of factory front bumper. Follow the instructions below:



**Fig.1**

### **PREMOUNTING PREPARATION**

1. Using four spring clamps, attach the new front spoiler to the bottom of factory bumper so that it sits evenly against the surface and lines up with the bottom of the grille opening and around the bottom of bumper (See Figs 1 and 2).



**Fig.2**

2. Drill two 1/8" holes approx. 3/8" in from back edge of spoiler through the top of spoiler and the bottom of bumper while the parts are clamped together, (repeat on both sides) (see fig.2) At this time leave spoiler clamped to bumper and locate the body screw that is at the very center bottom of bumper, remove screw and mark spot on center top surface of spoiler. Drill 1/8" hole on marked center spot. (see fig.3)



**Fig.3**

3. Now with all holes drilled, remove spoiler and install the spring clip nuts onto the spoiler (see fig.4) two on each side. Now you are ready to reinstall the spoiler onto car, for final adjustment before paint. Using the screws supplied (should be five) one for center, two on each side. Attach spoiler on car with screws and make any adjustments needed. If everything lines up, remove spoiler if you are planning to paint it, and follow the PREP/PAINT GUIDE SHEET.



**Fig.4**

